



## Repair Code Description

- 1 Replace 240v 13A plug – plastic
- 2 Replace 240v 13A plug – rubber
- 3 Change plug fuse 3A
- 4 Change plug fuse 5A
- 5 Change plug fuse 10A
- 6 Change plug fuse 13A
- 7 Replace 240v trailing socket
- 8 Replace 240v 16A plug
- 9 Replace 240v 16A connector
- 10 Replace 110v 16A plug
- 11 Replace 110v 16A connector
- 12 Replace 110v 16A panel mount socket
- 13 Trim, refit cable to appliance
- 14 Trim, refit cable to plug, or socket
- 15 Trim, refit cable to 240/110v 16A plug/connector/socket
- 16 Trim refit cable to 3-phase plug/connector/socket
- 17 Replace 15A/5A/2A plug
- 18 Trim, refit cable to fuse connection unit
- 19 Fit 10A flexible lead connector
- 20 Replace 1.5 Arctic Yellow/Blue cable 0-2m
- 21 Replace 1.5 Arctic Yellow/Blue cable 3-5m
- 22 Replace 1.5 Arctic Yellow/Blue cable 6-10m
- 23 Replace 1.5 Arctic Yellow/Blue cable 11 -1 5m
- 24 Replace 2.5 Arctic Yellow cable 0-2m
- 25 Replace 2.5 Arctic Yellow cable 3-5m
- 26 Replace 2.5 Arctic Yellow cable 6-10m
- 27 Replace 2.5 Arctic Yellow cable 11-15m
- 28 Replace 1.5 3 Core cable 0-2m
- 29 Replace 1.5 3 Core cable 3-5m
- 30 Replace 1.5 3 Core cable 6-10m
- 31 Replace 1.5 3 Core cable 11-15m
- 32 Replace 1.0 3 Core cable 0-2m
- 33 Replace 1.0 3 Core cable 3-5m
- 34 Replace 1.0 3 Core cable 6-10m
- 35 Replace 1.0 3 Core cable 11-15m
- 36 Replace 0.75 2 Core cable 0-2m
- 37 Replace 0.75 2 Core cable 3-5m
- 38 Replace 0.75 2 Core cable 6-10m
- 39 Replace 0.75 2 Core cable 11-15m
- 40 Supply 4 way extension lead complete
- 41 Supply and fit 4 way trailing socket
- 42 Supply and fit 2 way trailing socket
- 43 Supply kettle lead/complete with plug
- 44 Replace IEC plug/socket
- 45 Replace IEC computer lead
- 46 Replace cotton covered flex 2-3m
- 47 Fit 13A flex connector
- 48 Supply class 2 reversible mains lead
- 49 Fit 16/20/25mm cord grip bush
- 50 Fit strain relief bush